


OLYMPUS MOUNTING

ENDCAP
ORIENTATION




MONITOR
ORIENTATION




PENTAX MOUNTING

ENDCAP
ORIENTATION



MONITOR
ORIENTATION




FUJI MOUNTING

ENDCAP
ORIENTATION

Light
Source
Camera
Lens
Light
Source

Initial Position




Channel
Water Jet
(EG-600WR)



After
Tensioning
Straps

6 O'clock Position



Default Positions

7 O'clock Position



MONITOR
ORIENTATION

